

2304 Spring Ridge Dr. Unit A Spring Grove, IL 60081



Massive Speed System Ford Focus 00-04 Zetec Coil Pack Installation

- Make sure car is parked on a level surface with the parking brake engaged.
- Open hood, set prop rod in position
- Disconnect plug from coil

pack. You will need to press down on the clip from underneath the plug. (Fig 1)

- Remove plug wires. When pulling off wires, always pull on the boot to avoid damaging connections.
- Remove 4 bolts from coil pack using a T-25 Torx style screw driver/bit.
- Some vehicles coil plugs already have a rubber gasket. If so, remove the gasket from the new coil. The ring is not attached to the coil and is easily removed with a small screw driver or hook tool. (Fig. 2)
- Place 4 provided spacers on coil bracket over the 4 screw holes. (Fig.3)
- Apply a thread locker to the end of the bolts. Drop in provided bolts, start threads one at a time, tighten when all bolts have been properly located with a 4mm Allen key.
- Reconnect plug to coil pack.
- Install plug wires. Wires are numbered. You will notice a detent feeling when wires are properly installed onto plugs. Follow diagram. (Fig. 4)
- Remove all tools from engine compartment and test operation. If there are any problems, check that plug wires are properly seated.



Fig. 1 Coil pack location



Fig.2 Gasket Ring Removed




Fig. 3 Spacers positioned





Fig. 4 Plug wire orientation



Massive = Focus Performance Pros!!! Contact us for ANY Focus need!