



2304 Spring Ridge Dr. Unit A Spring Grove, IL 60081

Massive Speed System Ford Focus 06+ OMNI-KIT Installation

- Some years of Foci may require the larger diameter 00-07 Focus stamped steel "spring top hats" (Ford ONLY - Part number YS4Z-5793-BA). This may be a good time to replace the OE strut bearing and mount with either Ford or aftermarket pieces.
- Make sure car is parked on a level surface with the parking brake engaged
- Always support vehicle with jack stands
- Remove front struts per manufacturers instructions
- Coat new strut (any 00-05 style strut) base with included anti-seize compound
- Slide OMNI-KIT Bushing onto strut with slot aligned to strut alignment tab, flanged side on top of spindle
- Coat outside of OMNI-KIT bushing with included anti-seize compound
- Install strut/spring assembly into spindle per manufacturers instructions
- Align tab of strut with hole in spindle
- Use ONLY included hardware to affix, using a flat washer on each side and a lock washer on the nut side
- Face nut side AWAY from end link to avoid interference
- Torque to 80 Ft Lbs
- Complete remainder of suspension install per manufacturers instructions
- Enjoy

Massive = Focus Performance Pros!!! Contact us for ANY Focus need!

1.815.675.1822

www.massivespeedsystem.com